



Originale	Sostituto
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TV/AV	 AV
 TV / R	 TV/R
 Menu	 Menu
 Exit	 Exit
 Up	 Up

Originale	Sostituto
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 FAV	 Pre Ch
 EPG	 Guide
 V +	 Vol +
 V -	 Vol -
 Audio	 Info
 Info	 Dual
 Zoom	 Eject
 CH+/Page+	 Ch +
 CH-/Page-	 Ch -
 Red / SAT	 Red
 Green / Text	 Green
 Green / Text	 Text
 Yellow / Sub	 Yellow





Originale		Sostituto		Originale		Sostituto	
	Yellow / Sub		Subt				
	Red / SAT		Smart				
	Blue / <--PR		Blue				
	Blue / <--PR		Back				
	Pause		Pause				
	<I		I<<				
	I>		>>I				
	Rec		Rec				
	Play		Play				
	<<		<<				
	>>		>>				
	Stop		Stop				

