







































































Originale	Sostituto
	 Power
	 TV/R
	 AV
	 1
	 2
	 3
	 4
	 5
	 6
	 7
	 8
	 9
	 0
	 Pre Ch
	 Info
	 Shift + Pre Ch
	 Shift + Format

Originale	Sostituto
	 Shift + Dual
	 Vol +
	 Vol -
	 Mute
	 Ch +
	 Ch -
	 Menu
	 Guide
	 Up
	 Down
	 Right
	 Left
	 Ok
	 Dual
	 List
	 Eject
	 Exit





	Originale	Sostituto	
Browse Radio	Radio / Browse	SHIFT + SEARCH TV/R	Shift + TV/R
Rotate T.Shift	T.Shift / Rotate	SHIFT + TIMER AV	Shift + AV
Page up Audio	Audio / Page up	SHIFT + + CH	Shift + Ch +
Page up Audio	Audio / Page up	SHIFT + AD SUBT	Shift + Subt
Page down Subtitle	Subtitle / Page down	AD SUBT	Subt
Page down Subtitle	Subtitle / Page down	SHIFT + CH -	Shift + Ch -
D/EMP	D/EMP	HOME SMART	Smart
Media PVR	Media / PVR	APP MEDIA	Media
Play/Pause	Play / Pause	PLAY MODE	Play
Play/Pause	Play / Pause	II	Pause
Stop	Stop	■	Stop
Red / <<<	Red / <<<	A	Red
Red / <<<	Red / <<<	<<<	<<<
Green / >>>	Green / >>>	B	Green
Green / >>>	Green / >>>	>>>	>>>
Yellow / I<<<	Yellow / I<<<	C	Yellow
Yellow / I<<<	Yellow / I<<<	<<<	I<<<

	Originale	Sostituto	
Blue / >>I	Blue / >>I	D	Blue
Blue / >>I	Blue / >>I	>>I	>>I
Text / Setup	Text / Setup	REPEAT TEXT	Text
Size	Size	PICTURE FORMAT	Format
Reveal	Reveal	SETTINGS OPT	Options
Cancel	Cancel	RETURN BACK	Back
Sleep Hold	Hold / Sleep	PROG SLEEP	Sleep
Index	Index	SHIFT + DISPLAY INFO	Shift + Info
Internet Sub.Code	Sub.Code /	ECO 3D	3D
Mix	Mix	SHIFT + SETTINGS OPT	Shift + Options

