




















































































Originale	Sostituto
 Power	 Power
 Sleep	 Sleep
 Party	 Text
 Pure Direct	 Eject
 HDMI Out	 AV
 Scene	 Media
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 Input+	 Pre Ch
 Input-	 Guide
 TUNER	 Red

Originale	Sostituto
 NET	 Green
 USB	 Yellow
 BLUETOOTH	 Blue
 Preset+	 Shift + Right
 Preset-	 Shift + Left
 Red	 Shift + Red
 Green	 Shift + Green
 Yellow	 Shift + Yellow
 Blue	 Shift + Blue
 Settings	 Options
 List	 List
 Back	 Back
 ?	 Info
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left









































































Originale	Sostituto
 Enter	 Ok
 Top Menu	 D. Menu
 Top Menu	 Shift + Menu
 Home	 Smart
 Pop-Up / Menu	 Menu
 Enhancer	 Shift + 1
 Surr. Decode	 Shift + 2
 Bass	 Shift + 3
 Program+	 Ch +
 Program-	 Ch -
 Volume+	 Vol +
 Volume-	 Vol -
 Mute	 Mute
 Straight	 Shift + 4
 I<<	 I<<
 Play / Memory	 Play
 >>I	 >>I

Originale	Sostituto
 << / Tuning-	 <<
 Stop	 Stop
 Pause / Band	 Pause
 >> / Tuning+	 >>





Originale	Sostituto
 Power	 Power
 Sleep	 Sleep
 Party	 Text
 Pure Dierct	 Eject
 HDMI Out	 AV
 Scene	 Media
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 Input+	 Pre Ch
 Input-	 Guide
 TUNER	 Red

Originale	Sostituto
 NET	 Green
 USB	 Yellow
 BLUETOOTH	 Blue
 Preset+	 Shift + Right
 Preset-	 Shift + Left
 Red	 Shift + Red
 Green	 Shift + Green
 Yellow	 Shift + Yellow
 Blue	 Shift + Blue
 Settings	 Options
 List	 List
 Back	 Back
 ?	 Info
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left







Originale		Sostituto		Originale		Sostituto	
	↵ Enter		Ok		>> / Tuning+		>>
	Top Menu		D. Menu				
	Top Menu	+	Shift + Menu				
	Home		Smart				
	Pop-Up / Menu		Menu				
	Program+		Ch +				
	Program-		Ch -				
	Enhancer	+	Shift + 1				
	Volume+		Vol +				
	Volume-		Vol -				
	Mute		Mute				
	I<<<		I<<<				
	Play / Memory		Play				
	>>I		>>I				
	<<< / Tuning-		<<<				
	Stop		Stop				
	Pause / Band		Pause				

