



Originale	Sostituto
	Power
	Source
	3D / Invert
	Comp / Video
	Eco / Aspect
	Auto
	Blank / Mute
	Volt / Focus
	Help / Info
	Mode
	Shift + Menu
	Shift + Vol + / Page +
	Shift + Vol - / Page -
	Vol + / Page +
	Shift + Blank / Mute
	Freeze / Timer
	+ / Play

Originale	Sostituto
	- / Stop
	Vol - / Page -
	Menu
	Shift + Power
	Shift + Auto
	Shift + Mode
	Up
	Down
	Right
	Left
	Enter

