










































































































| Originale   | Sostituto   | Originale  | Sostituto   |
|-------------|---|------------|---|
| PWR On/Off  |  Power   | OK Enter   |  Ok    |
| Mute        |  Mute  | Menu Right |  Right |
| Epg         |  +  Shift + Guide | Exit       |  Exit  |
| App         |  Media   | Menu Down  |  Down  |
| Opt?        |  Options   | Audio      |  Dual  |
| TV          |  TV/R  | Back       |  Back  |
| Info        |  +  Shift + Info  | Volume+    |  Vol + |
| Subt.List   |  Subt  | CH/Page+   |  Ch +  |
| Sleep Timer |  Sleep   | Volume-    |  Vol - |
| Video       |  D. Menu   | CH/Page-   |  Ch -  |
| Text        |  Text  | 1. ?       |  1   |
| Zoom        |  Eject   | 2abc       |  2   |
| TV/SAT      |  AV  | 3def       |  3   |
| Menu        |  Menu  | 4ghi       |  4   |
| Menu Up     |  Up  | 5jkl       |  5   |
| Display     |  Info  | 6mno       |  6   |
| Menu Left   |  Left  | 7pqrm      |  7   |




| Originale    | Sostituto   | Originale     | Sostituto   |
|--------------|---|---------------|---|
| 8tuv         |  8               | +             |  Shift + Subt    |
| 9wxyz        |  9               | Auth./DISEQC  |  Shift + Smart   |
| Guide Pilote |  Guide           | Sys/Serv      |  Shift + Sleep   |
| 0/10         |  0               | Home Cinema   |  Smart           |
| FAV Pref.    |  Pre Ch          | Scan/Setup    |  Shift + Options |
| Red          |  Red             | Interat       |  Shift + D. Menu |
| Green        |  Green           | Pers.         |  Shift + Eject   |
| Yellow       |  Yellow          | Tune-         |  Shift + Left    |
| Freeze       |  Stop            | East          |  >>I             |
| Blue         |  Blue            | H/V Play      |  Play            |
| Dev          |  List           | LNB F.Forward |  >>             |
| 22Khz        |  3D            | Lang./Rewind  |  <<            |
| West         |  I<<           | Alt/16:9      |  Format        |
| Radio        |  Shift + TV/R  | Aft/Caf       |  Shift + Ok    |
| On/Off       |  Shift + Power | Tune+         |  Shift + Right |
| Dec/Pause    |  Pause         |               |  Shift + Exit  |
|              |  Shift + Mute  | Browse        |  Shift + Back  |































































| Originale   | Sostituto   | Originale  | Sostituto   |
|-------------|---|------------|---|
| PWR On/Off  |  Power   | OK Enter   |  Ok    |
| Mute        |  Mute  | Menu Right |  Right |
| Epg         |  +  Shift + Guide | Exit       |  Exit  |
| Subt.List   |  Subt  | Menu Down  |  Down  |
| Opt?        |  Options   | Back       |  Back  |
| App         |  Media   | Audio      |  Dual  |
| Info        |  +  Shift + Info  | Volume+    |  Vol + |
| Sleep Timer |  Sleep   | CH/Page+   |  Ch +  |
| TV          |  TV/R  | Volume-    |  Vol - |
| Video       |  D. Menu   | CH/Page-   |  Ch -  |
| Text        |  Text   | 1. ?       |  1    |
| Zoom        |  Eject   | 2abc       |  2   |
| TV/SAT      |  AV  | 3def       |  3   |
| Menu        |  Menu  | 4ghi       |  4   |
| Menu Up     |  Up  | 5jkl       |  5   |
| Display     |  Info  | 6mno       |  6   |
| Menu Left   |  Left  | 7pqrm      |  7   |








| Originale    | Sostituto   |  |
|--------------|---|--|
| 8tuv         |  8   |  |
| 9wxyz        |  9   |  |
| Guide Pilote |  Guide   |  |
| 0/10         |  0   |  |
| FAV Pref.    |  Pre Ch  |  |
| Red          |  Red   |  |
| Green        |  Green   |  |
| Yellow       |  Yellow  |  |
| Blue         |  Blue  |  |
| On/Off       |  +  Shift + Power     |  |
| Scan/Setup   |  +  Shift + Options |  |
| Radio        |  +  Shift + TV/R  |  |
|              |  +  Shift + Mute  |  |
| 22Khz        |  List  |  |
| +            |  +  Shift + Subt  |  |
| Sys/Serv     |  +  Shift + Sleep |  |
| Pers.        |  +  Shift + Eject |  |

| Originale    | Sostituto   |  |
|--------------|---|--|
| SAT Sky      |  +  Shift + AV        |  |
| Navi Mode    |  +  Shift + Menu      |  |
| Browse       |  +  Shift + Media     |  |
| Search       |  +  Shift + Up        |  |
| Auth./DISEQC |  3D  |  |
| Tune-        |  +  Shift + Left      |  |
| Tune+        |  +  Shift + Right     |  |
| East         |  >>  |  |
|              |  +  Shift + Exit      |  |
| Lang./Rewind |  <<  |  |
| H/V Play     |  Play   |  |
| Store        |  +  Shift + Down  |  |
| Alt/16:9     |  Format  |  |
|              |  +  Shift + Vol + |  |
| Home Cinema  |  Smart   |  |
|              |  +  Shift + Vol - |  |







































| Originale   | Sostituto  | Originale | Sostituto   |
|-------------|--|-----------|---|
| PWR On/Off  |  Power  | Exit      |  Exit  |
| Mute        |  Mute   | Menu Down |  Down  |
| Opt?        |  Options  | Back      |  Back  |
| Info        |  +  Shift + Info | Volume+   |  Vol + |
| Subt.List   |  Subt   | CH/Page+  |  Ch +  |
| Sleep Timer |  Sleep  | Audio     |  Dual  |
| TV          |  TV/R   | Volume-   |  Vol - |
| Video       |  D. Menu  | CH/Page-  |  Ch -  |
| Text        |  Text   | 1. ?      |  1     |
| Zoom        |  Eject  | 2abc      |  2     |
| TV/SAT      |  AV   | 3def      |  3   |
| Menu        |  Menu   | 4ghi      |  4   |
| Menu Up     |  Up   | 5jkl      |  5   |
| Display     |  Info   | 6mno      |  6   |
| Menu Left   |  Left   | 7pqrm     |  7   |
| OK Enter    |  Ok   | 8tuv      |  8   |
| Menu Right  |  Right  | 9wxyz     |  9   |



| Originale     | Sostituto   | Originale | Sostituto |
|---------------|---|-----------|-----------|
| Guide Pilote  |    |           | Guide     |
| 0/10          |    |           | 0         |
| FAV Pref.     |    |           | Pre Ch    |
| Red           |    |           | Red       |
| Green         |    |           | Green     |
| Dec/Pause     |    |           | Pause     |
| Lang./Rewind  |    |           | <<        |
| Freeze        |    |           | Stop      |
| LNB F.Forward |    |           | >>        |
| H/V Play      |    |           | Play      |
| East          |   |           | >>        |
| Yellow        |  |           | Yellow    |
| Blue          |  |           | Blue      |
|               |   |           |           |
|               |   |           |           |
|               |   |           |           |
|               |   |           |           |




| Originale   | Sostituto   | Originale  | Sostituto   |
|-------------|---|------------|---|
| PWR On/Off  |  Power   | OK Enter   |  Ok    |
| Mute        |  Mute  | Menu Right |  Right |
| Epg         |  +  Shift + Guide | Exit       |  Exit  |
| Subt.List   |  Subt  | Menu Down  |  Down  |
| Opt?        |  Options   | Back       |  Back  |
| App         |  Media   | Audio      |  Dual  |
| Info        |  +  Shift + Info  | Volume+    |  Vol + |
| Sleep Timer |  Sleep   | CH/Page+   |  Ch +  |
| TV          |  TV/R  | Volume-    |  Vol - |
| Video       |  D. Menu   | CH/Page-   |  Ch -  |
| Text        |  Text   | 1. ?       |  1    |
| Zoom        |  Eject   | 2abc       |  2   |
| TV/SAT      |  AV  | 3def       |  3   |
| Menu        |  Menu  | 4ghi       |  4   |
| Menu Up     |  Up  | 5jkl       |  5   |
| Display     |  Info  | 6mno       |  6   |
| Menu Left   |  Left  | 7pqrm      |  7   |





| Originale    | Sostituto   |                 |
|--------------|---|-----------------|
| 8tuv         |  8   | 8               |
| 9wxyz        |  9   | 9               |
| Guide Pilote |  GUIDE   | Guide           |
| 0/10         |  0   | 0               |
| FAV Pref.    |  PRE-CH  | Pre Ch          |
| Red          |  A   | Red             |
| Green        |  B   | Green           |
| Yellow       |  C   | Yellow          |
| Blue         |  D   | Blue            |
| On/Off       |  +      | Shift + Power   |
| Scan/Setup   |  +    | Shift + Options |
|              |  +  | Shift + Mute    |
| Dec/Pause    |    | Pause           |
| +            |  +  | Shift + Subt    |
| Sys/Serv     |  +  | Shift + Sleep   |
| Interat      |  +  | Shift + D. Menu |
| SAT Sky      |  +  | Shift + AV      |

| Originale   | Sostituto   |               |
|-------------|---|---------------|
| 22Khz       |  List  | List          |
| Radio       |  +      | Shift + TV/R  |
| Navi Mode   |  +      | Shift + Menu  |
| Search      |  +      | Shift + Up    |
| Tune-       |  +      | Shift + Left  |
| Tune+       |  +      | Shift + Right |
|             |  +      | Shift + Exit  |
| Store       |  +      | Shift + Down  |
|             |  +      | Shift + Vol + |
|             |  +      | Shift + Ch +  |
|             |  +    | Shift + Vol - |
| Home Cinema |  Smart   | Smart         |
|             |  +  | Shift + Ch -  |
| De-emph     |  +  | Shift + 1     |
| Swap        |  +  | Shift + 2     |
| P.lock      |  +  | Shift + 3     |
| Wn          |  +  | Shift + 4     |



