







































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Source	 AV
 Mute	 Mute	 Menu	 Menu
 TV	 Media	 DTV Guide	 Guide
 Text	 Text	 Up	 Up
 Info	 Info	 Down	 Down
 PIP	 Smart	 Right	 Right
 1	 1	 Left	 Left
 2	 2	 Enter	 Ok
 3	 3	 PR+	 Ch +
 4	 4	 PR-	 Ch -
 5	 5	 Vol+	 Vol +
 6	 6	 Vol-	 Vol -
 7	 7	 Exit	 Exit
 8	 8	 ARC	 3D
 9	 9	 Recall	 Back
 0	 0	 Mix	 Shift + Text
 -/--	 Shift + Guide	 Subpage	 Subt

Originale	Sostituto	Originale	Sostituto
 Source	 AV	 Source	 AV
 Menu	 Menu	 Menu	 Menu
 DTV Guide	 Guide	 DTV Guide	 Guide
 Up	 Up	 Up	 Up
 Down	 Down	 Down	 Down
 Right	 Right	 Right	 Right
 Left	 Left	 Left	 Left
 Enter	 Ok	 Enter	 Ok
 PR+	 Ch +	 PR+	 Ch +
 PR-	 Ch -	 PR-	 Ch -
 Vol+	 Vol +	 Vol+	 Vol +
 Vol-	 Vol -	 Vol-	 Vol -
 Exit	 Exit	 Exit	 Exit
 ARC	 3D	 ARC	 3D
 Recall	 Back	 Recall	 Back
 Mix	 Shift + Text	 Mix	 Shift + Text
 Subpage	 Subt	 Subpage	 Subt





Originale	Sostituto
 Hold	 Options
 Size	 Eject
 Reveal	 Shift + Options
 Update	 Play
 Index	 Shift + Info
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Text Store	 Pause
 Blue	 Blue
 PIP Prog+	 >>
 S.Select	 Sleep
 PIP Prog-	 <<
 DTV Page-	 I<<
 DTV Setup	 D. Menu
 Tv/Radio	 TV/R
 DTV Page+	 >>I

Originale	Sostituto
 PC	 Shift + Media
 Dual I-II	 Dual
 Sleep/Timer	 Shift + Power
 Still	 Shift + Subt
 SSM	 Shift + Dual
 Text List	 List
 PSM	 Format
 DTV Fav	 Pre Ch
 PIP Input	 Shift + Red
 PIP Position	 Shift + Yellow
 PIP Size	 Shift + Green
 Swap	 Shift + Back

