



































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		0		0
	Open/Close		Eject		Return		Back
	FM		Red		XTS Pro		Media
	DVD		Green		Marker		Format
	AUX		Yellow		Search		TV/R
	USB		Blue		O)))/Audio		Dual
	Sleep		Sleep		Sound		Shift + Dual
	Dimmer		D. Menu		[...]/Subtitle		Subt
	1		1		VSM		Smart
	2		2		Setup		Options
	3		3		Display		Info
	4		4		Up		Up
	5		5		Preset+		Ch +
	6		6		Down		Down
	7		7		Preset-		Ch -
	8		8		Right/Tun.+		Right
	9		9		Left/Tun-		Left



