







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Menu		Menu
	Mute		Mute		Red		Red
	Source		AV		Green		Green
	Sleep		Sleep		Yellow		Yellow
	V-Format		Format		Blue		Blue
	Wide		Eject		List		List
	1		1		Guide		Guide
	2		2		Up		Up
	3		3		Left		Left
	4		4		OK		Ok
	5		5		Right		Right
	6		6		Down		Down
	7		7		Exit		Exit
	8		8		Back		Back
	9		9		Vol+		Vol +
	0		0		Vol-		Vol -
	Text		Text		i		Info





Originale		Sostituto		Originale		Sostituto	
	OPT+		Options				
	P+		Ch +				
	P-		Ch -				
	Schedule		Smart				
	Audio		Dual				
	Sub		Subt				
	Tv/Radio		TV/R				

