





































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Green		Green
	Mute		Mute		Yellow		Yellow
	TV/AV		AV		Blue		Blue
	TXT/TV		Text		Stop		Pause
	1		1		Cancel		Exit
	2		2		Size		Eject
	3		3		Recall/Reveal		Back
	4		4		F		Ok
	5		5		Up		Up
	6		6		P+		Ch +
	7		7		Down		Down
	8		8		P-		Ch -
	9		9		Right		Right
	0		0		Vol+		Vol +
	P↔P / List		Pre Ch		Left		Left
	-/--		Guide		Vol-		Vol -
	Red		Red		Menu/Index		Menu



