







































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Menu	 Menu
 Source	 AV	 Guide	 Guide
 P.Mode	 Format	 Back	 Back
 S.Mode	 Dual	 Exit	 Exit
 Home	 Smart	 Up	 Up
 1	 1	 Down	 Down
 2	 2	 Right	 Right
 3	 3	 Left	 Left
 4	 4	 OK	 Ok
 5	 5	 YouTube	 Media
 6	 6	 Vol +	 Vol +
 7	 7	 Vol -	 Vol -
 8	 8	 Mute	 Mute
 9	 9	 Tool	 TV/R
 0	 0	 CH +	 Ch +
 Q.View	 Options	 CH -	 Ch -
 Info	 Info	 FAV	 Pre Ch





Originale	Sostituto
 APP	 Shift + Media
 CH List	 List
	
 Play	 Play
	
 Stop	
 Pause	
 Rec	 Rec
 Red	 Red
 Green	 Green
 Yellow	 Yellow
 Blue	 Blue

Originale	Sostituto

