











































Originale	Sostituto
 Power	 Power
 Mute	 Mute
 Exit	 Exit
 Text	 Text
 Audio I/II	 Dual
 Display	 Info
 Sleep	 Sleep
 P+	 Ch +
 P-	 Ch -
 V+	 Vol +
 V-	 Vol -
 Red / Source	 AV
 Red / Source	 Shift + Red
 Green / TV	 Menu
 Green / TV	 Shift + Green
 Yellow / PMode	 Format
 Yellow / PMode	 Shift + Yellow

Originale	Sostituto
 Blue / SMode	 Shift + Dual
 Blue / SMode	 Shift + Blue
 Up	 Up
 Left	 Left
 Enter	 Ok
 Right	 Right
 Down	 Down
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0





Originale	Sostituto
	+  Shift + Guide
	Back
	Red
	Green
	Yellow
	Blue
	+  Shift + Text
	Subt
	Play
	Pause
	3D
	D. Menu
	+  Shift + Info
	Eject
	I<<
	>>I
	Stop

Originale	Sostituto
	+  Shift + Left
	<<
	Pre Ch
	>>
	+  Shift + Right
	Guide
	Media
	Rec
	List
	TV/R

