






























Originale	Sostituto
 Power	 Power
 Repeat	 Text
 Program	 Shift + Sleep
 Shuffle	 Guide
 Tape A/R	 Pre Ch
 Display	 Info
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Title >	 >>
 < Title	 <<
 Stop	 Stop
 Play/Pause	 Play
 Album >>	 >>
 << Album	 <<
 Clock	 Smart
 Timer On/Off	 TV/R

Originale	Sostituto
 Timer	 AV
 Natural	 Back
 Rec	 Rec
 DIM	 Media
 Sleep	 Sleep
 Snooze	 Exit
 Bass+	 Right
 Bass-	 Left
 Treble+	 Ch +
 Treble-	 Ch -
 Inc Surr.	 Menu





Originale	Sostituto
 Power	 Power
 Program	 Sleep
 Tape A/R	 Pre Ch
 Display	 Info
 Vol+	 Vol +
 Vol-	 Vol -
 Title >	 >>
 I< Title	 I<<
 Stop	 Stop
 Play/Pause	 Play
 Album >>	 >>
 << Album	 <<

Originale	Sostituto





Originale	Sostituto	Originale	Sostituto
 Power	 Power		
 Repeat	 Text		
 Program	 Sleep		
 Shuffle	 Guide		
 Tape A/R	 Pre Ch		
 Display	 Info		
 Vol+	 Vol +		
 Vol-	 Vol -		
 Title >	 >>		
 I < Title	 I <<		
 Stop	 Stop		
 Play/Pause	 Play		
 Album >>	 >>		
 << Album	 <<		

Originale	Sostituto

