

















Originale	Sostituto
MUTE	Mute
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
-/--	Guide
AV	AV
Menu	Menu
Red	Red
OK	Ok

Originale	Sostituto
Green	Green
P:P	Pre Ch
Yellow	Yellow
Analog	Smart
Blue	Blue
Up	Up
P+	Ch +
P-	Ch -
Down	Down
Right	Right
Vol+	Vol +
Vol-	Vol -
Left	Left
Recall	Back
Sleep	Sleep
Status	3D
Tv/TXT	Text





Originale	Sostituto
 Stop	 Stop
 Reveal	 Media
 Size	 Format
 Mix	 Options
 Index	 Info
 Subcode	 Subt
 Cancel	 Shift + Back

Originale	Sostituto

