





Originale	Sostituto
 Power	 Power
 Sleep	 Sleep
 Timer/Play	 AV
 Clock/Timer	 Shift + AV
 Program	 Shift + Sleep
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9

Originale	Sostituto
 0	 0
 +10	 Guide
 Del	 Exit
 Bluetooth	 Green
 CD/USB	 Yellow
 Radio/EXT-IN	 Blue
 I<<	 I<<
 Pause	 Pause
 Play	 Play
 >>I	 >>I
 <<	 <<
 Stop	 Stop
 >>	 >>
 D.Bass	 Subt
 Sound	 Dual
 Preset EQ	 Text
 Display	 Info





Originale	Sostituto
Dimmer	3D
Play Menu	Menu
Setup	Options
Radio Menu	D. Menu
Up	Up
Down	Down
Right	Right
Left	Left
OK	Ok

Originale	Sostituto

