
















| Originale   |                 | Sostituto   |               | Originale   |               | Sostituto   |               |
|---|-----------------|---|---------------|---|---------------|---|---------------|
|    | System          |    | Power         |    | Vol+          |    | Vol +         |
|    | Sleep           |    | Sleep         |    | Vol-          |    | Vol -         |
|    | CD/HDD/USB/N    |    | Smart         |    | Setup         |    | Options       |
|    | Function        |    | D. Menu       |    | Menu          |    | Menu          |
|    | SDB/Tone        |    | Media         |    | Up            |    | Up            |
|    | Prog            |   | Shift + Sleep |    | Left          |    | Left          |
|    | Random          |    | TV/R          |    | Push/Enter    |    | Ok            |
|    | Repeat          |    | Text          |    | Right         |    | Right         |
|    | Play/Pause HDD  |    | Play          |    | Down          |    | Down          |
|    | Play/Pause CD   |    | Pause         |    | Time/Display  |    | Info          |
|   | Stop/Band       |   | Stop          |   | Back          |   | Back          |
|  | I<</CH-         |  | I<<           |  | Music Search  |  | Dual          |
|  | >>/CH+          |  | >>I           |  | < Tape        |  | Ch -          |
|  | <</Tu-          |  | <<            |  | Tape >        |  | Ch +          |
|  | >>/TU+          |  | >>            |  | Stop MD/Tape  |  | Shift + Stop  |
|  | Play/Pause iPod |  | Blue          |  | Play/Pause MD |  | Shift + Pause |
|  | Mute            |  | Mute          |  | Tape          |  | Shift + Smart |





| Originale |          | Sostituto |               | Originale |          | Sostituto |        |
|-----------|----------|-----------|---------------|-----------|----------|-----------|--------|
|           | MD       |           | Shift + Media |           | CD Store |           | Rec    |
|           | Genre    |           | Green         |           | 1        |           | 1      |
|           | Artist   |           | Yellow        |           | 2        |           | 2      |
|           | Album    |           | Shift + Guide |           | 3        |           | 3      |
|           | Track    |           | Eject         |           | 4        |           | 4      |
|           | P.List   |           | Red           |           | 5        |           | 5      |
|           | Line 1/2 |           | AV            |           | 6        |           | 6      |
|           | Dimmer   |           | Format        |           | 7        |           | 7      |
|           | Folder   |           | Shift + Info  |           | 8        |           | 8      |
|           | Clock    |           | Shift + AV    |           | 9        |           | 9      |
|           | Up       |           | Shift + Up    |           | 0/10     |           | 0      |
|           | Left     |           | Shift + Left  |           | +10      |           | Guide  |
|           | Enter    |           | Shift + Ok    |           | Clear    |           | Exit   |
|           | Right    |           | Shift + Right |           | Call     |           | Pre Ch |
|           | Down     |           | Shift + Down  |           |          |           |        |
|           | Back     |           | Shift + Back  |           |          |           |        |
|           | Edit     |           | Subt          |           |          |           |        |

