

























































Originale	Sostituto
 Power	 Power
 Input	 AV
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Guide	 Guide
 CH.List	 List
 Play	 Play
 Red	 Red
 Green	 Green

Originale	Sostituto
 Yellow	 Yellow
 Blue	 Blue
 [=]	 Menu
 Pause	 Pause
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Back	 Back
 Exit	 Exit
 Vol+	 Vol +
 Vol-	 Vol -
 Home	 Smart
 Micro	 Media
 CH+	 Ch +
 CH-	 Ch -





Originale		Sostituto	
	Subtitle		Subt
	Mute		Mute
	Text		Text
	Free		Options
	Sports		TV/R
	Chili		Dual
	Netflix		Shift + Media
	prime video		3D
	YouTube		Pre Ch
	TV Timvision		Shift + TV/R
	Rakuten Tv		D. Menu
	Rai Play		Shift + Smart

Originale	Sostituto

