



| Originale | Sostituto | Originale | Sostituto |
|---|---|---|--|
|  Power |  Power |  Left |  Left |
|  Mute |  Mute |  OK |  Ok |
|  1 |  1 |  Right |  Right |
|  2 |  2 |  Down |  Down |
|  3 |  3 |  Menu |  Menu |
|  4 |  4 |  Exit |  Exit |
|  5 |  5 |  Vol+ |  Vol + |
|  6 |  6 |  Vol- |  Vol - |
|  7 |  7 |  P.Mode |  Format |
|  8 |  8 |  S.Mode |  Dual |
|  9 |  9 |  CH+ |  Ch + |
|  0 |  0 |  CH- |  Ch - |
|  - |  Guide |  Input |  Shift + AV |
|  Recall |  Back |  Fav / Angle |  Pre Ch |
|  Source |  AV |  Zoom |  Eject |
|  Display |  Info |  Sleep |  Sleep |
|  Up |  Up |  Red |  Red |





| Originale | | Sostituto | | Originale | Sostituto |
|-----------|--------------|-----------|---------|-----------|-----------|
| | Green / 3D | | Green | | |
| | Green / 3D | | 3D | | |
| | Yellow | | Yellow | | |
| | Blue | | Blue | | |
| | Play / Pause | | Play | | |
| | Play / Pause | | Pause | | |
| | FR | | << | | |
| | FF | | >> | | |
| | Stop | | Stop | | |
| | Prev | | I<< | | |
| | Next | | >>I | | |
| | Media | | Media | | |
| | Keyboard | | Text | | |
| | PC | | D. Menu | | |
| | Refresh | | List | | |
| | Search | | TV/R | | |
| | Home | | Smart | | |

