



Originale	Sostituto
 Power	 Power
 Mute	 Mute
 Red / Eject	 Red
 Red / Eject	 Eject
 Green / Title	 Green
 Yellow / DVD	 Yellow
 Yellow / DVD	 Options
 Blue / A-B	 Blue
 <</[≡o]	 <<
 >>/[≡?]	 >>
 <</[≡+]	 <<
 >> /[≡..]	 >>
 Play	 Play
 Pause	 Pause
 Stop	 Stop
 Angle / [≡i]	 Smart
 Return / Text	 Text

Originale	Sostituto
 Return / Text	 Shift + Back
 Subtitle	 Subt
 Display	 Shift + Info
 Menu / Info	 Info
 Menu / Info	 D. Menu
 Menu	 Menu
 Up	 Up
 Source	 AV
 Left	 Left
 OK	 Ok
 Right	 Right
 EPG	 Guide
 Down	 Down
 Exit	 Exit
 Vol+	 Vol +
 FAV	 Pre Ch
 CH+	 Ch +



