







| Originale | Sostituto |
|---|---|
|  Power |  Power |
|  Mute |  Mute |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |
|  8 |  8 |
|  9 |  9 |
|  0 |  0 |
|  Timeshift |  Sleep |
|  Recall |  Back |
|  Mark |  Options |
|  Tv/Radio |  TV/R |
|  Source |  AV |

| Originale | Sostituto |
|---|---|
|  Info |  Info |
|  Menu |  Menu |
|  Exit |  Exit |
|  Text |  Text |
|  EPG |  Guide |
|  Up |  Up |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  OK |  Ok |
|  << |  << |
|  >> |  >> |
|  Stop |  Stop |
|  Play |  Play |
|  Pause |  Pause |
|  Rec |  Rec |
|  I<< |  I<< |



