



Originale	Sostituto
POWER	Power
AUTO SETUP	Auto
COMPUTER 1	Comp / Video
COMPUTER 2	Shift + Mode
HDMI	Mode
VIDEO	Shift + Comp / Video
S-VIDEO	Volt / Focus
COMPONENT	3D / Invert
DIGITAL LINK	Shift + Menu
▲	Up
▼	Down
>	Right
<	Left
ENTER	Enter
MENU	Menu
SCREEN	Source
KEYSTONE	Shift + Up

Originale	Sostituto
INFO	Help / Info
LAMP	Shift + Auto
FREEZE	Freeze / Timer
AV MUTE	Blank / Mute
P-TIMER	Shift + Freeze / Timer
D.ZOOM +	+ / Play
D.ZOOM -	- / Stop
VOL +	Vol + / Page +
VOL -	Vol - / Page -
IMAGE	Eco / Aspect
MUTE	Shift + Blank / Mute

