
































Originale	Sostituto
 Power	 Power
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 TV	 TV/Radio /
 Radio	 Display / Media
 Audio	 Audio / Lang I/II
 Info	 Info / Angle
 Guide	 Guide / EPG / -/--

Originale	Sostituto
 [...]	 Subtitle / EQ
 Up	 Up
 OK	 OK
 Down	 Down
 Right	 Right
 Left	 Left
 V+	 Vol+
 V-	 Vol-
 Menu	 Menu / Home
 Quitter	 Exit / Cancel / Clear
 P+	 CH+ / Page+
 P-	 CH- / Page-
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 [=]	 Text / Goto





	Originale	Sostituto	Originale	Sostituto
	♥	 Fav / Marker / PC		
	Back	 Back / Return		
	> <	 Picture / Format		

