


Originale		Sostituto		Originale		Sostituto	
	Power		Power		Sound		Sound / Title
	Vol+		Vol+		Green		Green / APP / Repeat
	Vol-		Vol-		List		Shift + Smart / List
	Mute		Mute / Dimmer		Yellow		Yellow / YouTube / Repeat
	Return		Back / Return		Info		Info / Angle
	PR+		CH+ / Page+		Mosaic		Smart / List
	>>		>>  / Preset+		Blue		Blue / Prime Video / Random
	<<		<< / Preset-		Violet		Display / Media
	PR-		CH- / Page-		Text		Text / Goto
	Exit		Exit / Cancel / Clear		1		1
	Menu		Menu / Home		2		2
	Up		Up		3		3
	Down		Down		4		4
	Right/Zoom+		Right		5		5
	Left/Zoom-		Left		6		6
	OK		OK		7		7
	Red		Red / Netflix / Search		8		8







Originale	Sostituto
 9	 9
 0/-/-	 0
 AV	 AV / Input / RDS
 PIP	 Zoom / Size
 <</Pat-Mix	 << / Tune-
 Play/?	 Play / Slow
 >>	 >> / Tune+
 Rec/100	 Rec / Rec Mode
 Stop	 Stop / Hold
 Pause/---	 Pause / Step / Freeze
 Swap PIP	 Setup / OPT /
 Size PIP	 Picture / Format
 Position PIP	 TV/Radio /

Originale	Sostituto








Originale	Sostituto
 Power	 Power
 Vol+	 Vol+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 Return	 Back / Return
 PR+	 CH+ / Page+
 >>	 >>  / Preset+
 PR-	 CH- / Page-
  <<	  << / Preset-
 Exit	 Exit / Cancel / Clear
 Menu	 Menu / Home
 Up	 Up
 Down	 Down
 Right/Zoom+	 Right
 Left/Zoom-	 Left
 OK	 OK
 Red	 Red / Netflix / Search



































Originale	Sostituto
 Sound	 Sound / Title
 Green	 Green / APP / Repeat
 List	 Shift + Smart / List
 Info	 Info / Angle
 Yellow	 Yellow / YouTube / Repeat
 Mosaic	 Smart / List
 Blue	 Blue / Prime Video / Random
 Violet	 Display / Media
 Text	 Text / Goto
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8











Originale	Sostituto
 Power	 Power
 Vol+	 Vol+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 Return	 Back / Return
 PR+	 CH+ / Page+
 >>	 >>  / Preset+
  <<	  << / Preset-
 PR-	 CH- / Page-
 Exit	 Exit / Cancel / Clear
 Menu	 Menu / Home
 Up	 Up
 Down	 Down
 Right/Zoom+	 Right
 Left/Zoom-	 Left
 OK	 OK
 Red	 Red / Netflix / Search

Originale	Sostituto
 Sound	 Sound / Title
 List	 Shift + Smart / List
 Green	 Green / APP / Repeat
 Info	 Info / Angle
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Mosaic	 Smart / List
 Violet	 Display / Media
 Text	 Text / Goto
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8



