







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Red		Red / Netflix / Search
	Tv/Radio		TV/Radio /		Green		Green / APP / Repeat
	Source		AV / Input / RDS		Yellow		Yellow / YouTube / Repeat
	1		1		Blue		Blue / Prime Video / Random
	2		2		Up		Up
	3		3		Down		Down
	4		4		Left		Left
	5		5		Right		Right
	6		6		OK		OK
	7		7		PR-		CH- / Page-
	8		8		PR+		CH+ / Page+
	9		9		Vol-		Vol-
	0		0		Vol+		Vol+
	OPT+		Setup / OPT /		Menu		Menu / Home
	Guide		Guide / EPG / -/--		i		Info / Angle
	Exit		Exit / Cancel / Clear		Audio?		Audio / Lang I/II
	Back		Back / Return		Text		Text / Goto



