

























































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Vol+	 Vol+
 Sleep	 Sleep / Timer	 Vol-	 Vol-
 PlayTimer	 Pause / Step / Freeze	 Mute	 Mute / Dimmer
 Clock/Timer	 Shift + Sleep / Timer	 Bluetooth	 Shift + 9
 1	 1	 CD/USB	 Red / Netflix / Search
 2	 2	 Radio/Ext-In	 Green / APP / Repeat
 3	 3	 I<<	 I<< / Preset-
 4	 4	 Play/Pause	 Play / Slow
 5	 5	 >>I	 >>I / Preset+
 6	 6	 <<	 << / Tune-
 7	 7	 Stop	 Stop / Hold
 8	 8	 >>	 >> / Tune+
 9	 9	 OK	 OK
 0	 0	 D.Bass	 Text / Goto
 DEL	 Exit / Cancel / Clear	 Sound	 Sound / Title
 +10	 Guide / EPG / EPG	 Preset EQ	 AV / Input / RDS
 Program	 TV/Radio /	 Display	 Display / Media

Originale	Sostituto	Originale	Sostituto
 DIMMER MUTE	 SHIFT	 TV	 DVD
 SLOW	 STEP-FREEZE	 HOLD	 REC MODE
 TUNE-	 TUNE+	 PRESET-	 PRESET+
 TITLE	 LANG III	 EQ	 SURROUND
 SOUND	 AUDIO	 SUBTITLE	 PROGRAM
 PICTURE	 ZOOM	 SLEEP	 TV RADIO
 TOP MENU	 OPT-TOOLS	 GOTO	 RDS
 D.MENU	 SETUP	 TEXT	 AV INPUT
 HOME	 ANGLE	 MENU	 INFO
 OK	 OK	RETURN	BACK
CLEAR	EXIT	CANCEL	LIST
VOL+	SMART	CH PAGE	CH PAGE
VOL-	MEDIA	DISPLAY	DISPLAY
TV	DVD	CD-STB	CD-STB
1	2	3	3
4	5	6	6
7	8	9	9
GUIDE EPG	HDMI-BAT	FC	FAV MARKER
NETFLIX	APP	YouTube	Prime Video
SEARCH	REPEAT	REPEAT A-B	RANDOM
Mandis SHOP			
www.mandis.it			



