











































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		CH-		CH- / Page-
	1		1		Exit		Exit / Cancel / Clear
	2		2		Red		Red / Netflix / Search
	3		3		Green		Green / APP / Repeat
	4		4		Yellow		Yellow / YouTube / Repeat
	5		5		Blue		Blue / Prime Video / Random
	6		6		Up		Up
	7		7		Down		Down
	8		8		Left		Left
	9		9		Right		Right
	0		0		OK		OK
	Text		Text / Goto		Menu		Menu / Home
	Back		Back / Return		APP		Shift + Green / APP /
	Mute		Mute / Dimmer		List		Smart / List
	Vol+		Vol+		i		Info / Angle
	Vol-		Vol-		EPG		Guide / EPG / -/-
	CH+		CH+ / Page+		ALT		Audio / Lang I/II





Originale	Sostituto
	 Subtitle / EQ
	 TV/Radio /

Originale	Sostituto

