



Originale	Sostituto
Power	Power
1	1
2	2
3	3
Canali+	CH+ / Page+
4	4
5	5
6	6
Canali-	CH- / Page-
7	7
8	8
9	9
Volume+	Vol+
0	0
Prec.	Back / Return
Riposo	Sleep / Timer
Volume-	Vol-

Originale	Sostituto
Muto / Normal	Mute / Dimmer
Timer Rec	D.Menu / Top
Prog. CFM	TV/Radio /
CAF	Info / Angle
Menu	Menu / Home
Counter	Red / Netflix / Search
Counter Reset	Green / APP / Repeat
Ricerca Set-	Left
Ricerca Set+	Right
Auto Tracking	Smart / List
Tracking	Down
Tracking	Up
Invio	OK
Cancel	Exit / Cancel / Clear
Slow	Shift + Play /
Index	Picture / Format
Clock	Setup / OPT /



