

















Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Source	 AV / Input / RDS
 Mute	 Mute / Dimmer	 Left	 Left
 1	 1	 Enter	 OK
 2	 2	 Right	 Right
 3	 3	 Exit	 Exit / Cancel / Clear
 Nicam	 Shift + Audio / Lang I/II	 Down	 Down
 4	 4	 Display	 Display / Media
 5	 5	 Vol+	 Vol+
 6	 6	 Sound	 Sound / Title
 Recall/Goto	 Back / Return	 CH+	 CH+ / Page+
 Recall/Goto	 Shift + Text /	 Vol-	 Vol-
 7	 7	 Pic	 Picture / Format
 8	 8	 CH-	 CH- / Page-
 9	 9	 Sleep	 Sleep / Timer
 0	 0	 Aspect	 Shift + Picture / Format
 TV Menu	 Menu / Home	 DVD/DVB Setup	 Setup / OPT /
 Up	 Up	 DVD Source	 Shift + AV / Input / RDS

Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Source	 AV / Input / RDS
 Mute	 Mute / Dimmer	 Left	 Left
 1	 1	 Enter	 OK
 2	 2	 Right	 Right
 3	 3	 Exit	 Exit / Cancel / Clear
 Nicam	 Shift + Audio / Lang I/II	 Down	 Down
 4	 4	 Display	 Display / Media
 5	 5	 Vol+	 Vol+
 6	 6	 Sound	 Sound / Title
 Recall/Goto	 Back / Return	 CH+	 CH+ / Page+
 Recall/Goto	 Shift + Text /	 Vol-	 Vol-
 7	 7	 Pic	 Picture / Format
 8	 8	 CH-	 CH- / Page-
 9	 9	 Sleep	 Sleep / Timer
 0	 0	 Aspect	 Shift + Picture / Format
 TV Menu	 Menu / Home	 DVD/DVB Setup	 Setup / OPT /
 Up	 Up	 DVD Source	 Shift + AV / Input / RDS





Originale	Sostituto
 Fav	 Fav / Marker / PC
 Text	 Text / Goto
 Info	 Info / Angle
 EPG	 Guide / EPG / -/--
 Return / Index	 Shift + Back / Return
 Title / Size	 Shift + Sound / Title
 Title / Size	 Zoom / Size
 Angle / Hold	 Shift + Stop /
 PBC / Subcode	 TV/Radio /
 Repeat / Reveal	 Shift + Green / APP /
 Play/Pause	 Play / Slow
 Stop	 Stop / Hold
 Open/Close	 Eject / Surround
 Red / <<	 << / Tune-
 Red / <<<	 Red / Netflix / Search
 Green / >>>	 >> / Tune+
 Green / >>	 Green / APP / Repeat

Originale	Sostituto
 Yellow / I<<<	 I<<< / Preset-
 Yellow / I<<<	 Yellow / YouTube / Repeat
 Blue / >>>I	 >>>I / Preset+
 Blue / >>>I	 Blue / Prime Video / Random
 DVD Menu	 D.Menu / Top
 Audio	 Audio / Lang I/II
 Subtitle	 Subtitle / EQ
 DVD Display	 Shift + Display / Media
 Rec	 Rec / Rec Mode
 Rec List	 Smart / List
 PVR Info	 Shift + Info / Angle
 PIP	 Shift + Smart / List

