




























| Originale | Sostituto | Originale | Sostituto |
|------------|---|-----------|---|
| On/Off |  Power | 5 |  5 |
| Mute |  Mute / Dimmer | 6 |  6 |
| Return TV |  TV/Radio / | 7 |  7 |
| Menu |  Menu / Home | 8 |  8 |
| Menu Up |  Up | 9 |  9 |
| Menu Left |  Left | 0/10 |  0 |
| OK Enter |  OK | Red |  Red / Netflix / Search |
| Menu Right |  Right | Green |  Green / APP / Repeat |
| Menu Down |  Down | Yellow |  Yellow / YouTube / Repeat |
| Volume+ |  Vol+ | Blue |  Blue / Prime Video / Random |
| Chan.Up |  CH+ / Page+ | | |
| Volume- |  Vol- | | |
| Chan.Down |  CH- / Page- | | |
| 1 |  1 | | |
| 2 |  2 | | |
| 3 |  3 | | |
| 4 |  4 | | |

