





































Originale	Sostituto
 Power	 Power
 TV / DTV	 TV/Radio /
 Source	 AV / Input / RDS
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Recall	 Back / Return
 0	 0
 Info	 Info / Angle
 Fav	 Fav / Marker / PC
 Picture	 Picture / Format

Originale	Sostituto
 Sound	 Sound / Title
 Vol+	 Vol+
 CH+	 CH+ / Page+
 Vol-	 Vol-
 Mute	 Mute / Dimmer
 CH-	 CH- / Page-
 Menu	 Menu / Home
 EPG	 Guide / EPG / -/-
 Up	 Up
 Left	 Left
 OK	 OK
 Right	 Right
 Down	 Down
 I/II	 Audio / Lang I/II
 Still	 Pause / Step / Freeze
 Zoom	 Zoom / Size
 Exit	 Exit / Cancel / Clear





Originale		Sostituto	
	Radio / Browse		Display / Media
	T.Shift / Rotate		Setup / OPT /
	Lang / Page Up		+ Shift + CH+ /
	Lang / Page Up		+ Shift + Audio / Lang I/II
	Subtitle / Page Down		+ Shift + CH- /
	Subtitle / Page Down		Subtitle / EQ
	DMP.		Smart / List
	PVR		D.Menu / Top
	Play / Pause		Play / Slow
	Stop		Stop / Hold
	Red / <<<		<<< / Tune-
	Red / <<<		Red / Netflix / Search
	Green / >>>		>>> / Tune+
	Green / >>>		Green / APP / Repeat
	Yellow / I<<<		I<<< / Preset-
	Yellow / I<<<		Yellow / YouTube / Repeat
	Blue / >>I		Blue / Prime Video / Random

Originale		Sostituto	
	Blue / >>I		>>I / Preset+
	Text		Text / Goto
	Size		+ Shift + Zoom /
	Reveal		Eject / Surround
	Cancel		+ Shift + Exit / Cancel / Clear
	Hold / Sleep		+ Shift + Stop /
	Hold / Sleep		Sleep / Timer
	Index		+ Shift + Info / Angle
	Sub. Code		+ Shift + Subtitle / EQ
	Mix		+ Shift + Text /

