



Originale	Sostituto
Power	Power
Input	AV / Input / RDS
Menu	Menu / Home
Picture	Picture / Format
Text	Text / Goto
STTL	Subtitle / EQ
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
i	Info / Angle
X/Exit	Exit / Cancel / Clear
Netflix	Shift + Red / Netflix /
prime video	Shift + Blue / Prime
Left	Left
Up	Up
Right	Right

Originale	Sostituto
Rakuten Tv	Display / Media
OK	OK
Back	Back / Return
Down	Down
Home	Shift + Menu /
Mute	Mute / Dimmer
Option	Setup / OPT /
Guide	Guide / EPG / -/-
List	Shift + Smart / List
Vol+	Vol+
Smart Colors	Smart / List
CH+	CH+ / Page+
Vol-	Vol-
CH-	CH- / Page-
1	1
2	2
3	3



