













































Originale	Sostituto
 Power	 Power
 TV/VCR	 TV/Radio /
 DVD	 Shift + 2
 CH/Page+	 CH+ / Page+
 1	 1
 2	 2
 3	 3
 CH/Page-	 CH- / Page-
 4	 4
 5	 5
 6	 6
 Vol+	 Vol+
 7	 7
 8	 8
 9	 9
 Vol-	 Vol-
 0/AV	 0

Originale	Sostituto
 0/AV	 AV / Input / RDS
 Display	 Info / Angle
 Setup / Menu	 Setup / OPT /
 Setup / Menu	 Menu / Home
 Up / Green	 Up
 Up / Green	 Green / APP / Repeat
 Mute	 Mute / Dimmer
 Left / Red	 Left
 Left / Red	 Red / Netflix / Search
 Enter/Text/Mix/TV	 OK
 Enter/Text/Mix/TV	 Text / Goto
 Right / Blue	 Right
 Right / Blue	 Blue / Prime Video / Random
 DVD Menu	 D.Menu / Top
 Down / Yellow	 Down
 Down / Yellow	 Yellow / YouTube / Repeat
 Cancel / F/T/B	 Exit / Cancel / Clear





Originale		Sostituto	
	<<		<< / Tune-
	Play		Play / Slow
	>>		>> / Tune+
	TRK/Skip- <<		<< / Preset-
	TRK/Skip- >>		>>  / Preset+
	Stop		Stop / Hold
	Pause/Still		Pause / Step / Freeze
	Rec/Otr		Rec / Rec Mode
	Timer Rec	 + 	Shift + Sleep / Timer
	Index/Sub page		Smart / List
	Slow	 + 	Shift + Pause / Step /
	Repeat	 + 	Shift + Yellow / YouTube /
	Repeat	 + 	Shift + TV/Radio / Program
	Jump/Hold/SP/L		Picture / Format
	Angle/Counter	 + 	Shift + Info / Angle
	Subtitle/Zero return		Subtitle / EQ
	Zoom/Reveal		Zoom / Size

Originale		Sostituto	
	Title/ATR		Sound / Title
	Return		Back / Return
	Play Mode/Quick View		Display / Media
	Sleep		Sleep / Timer
	Audio		Audio / Lang I/II
	Eject	 + 	Shift + Eject / Surround
	Open/Close		Eject / Surround

