



































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Up	 Up
 Mute	 Mute / Dimmer	 Exit	 Exit / Cancel / Clear
 1	 1	 Left	 Left
 2	 2	 OK	 OK
 3	 3	 Right	 Right
 4	 4	 Play	 Play / Slow
 5	 5	 Down	 Down
 6	 6	 Audio	 Audio / Lang I/II
 7	 7	 Pause	 Pause / Step / Freeze
 8	 8	 FAV	 Fav / Marker / PC
 9	 9	 Red/Zoom	 Red / Netflix / Search
 Tv/Radio	 TV/Radio /	 Green/9 Pic.	 Green / APP / Repeat
 0	 0	 Yellow	 Yellow / YouTube / Repeat
 Recall	 Back / Return	 Blue	 Blue / Prime Video / Random
 Info	 Info / Angle	 << / Tune-	 << / Tune-
 EPG	 Guide / EPG / -/--	 >> / Tune+	 >> / Tune+
 Menu	 Menu / Home	 Sub-T	 Subtitle / EQ

Originale	Sostituto	Originale	Sostituto
 Up	 Up	 Exit	 Exit / Cancel / Clear
 Left	 Left	 Right	 Right
 OK	 OK	 Play	 Play / Slow
 Down	 Down	 Audio	 Audio / Lang I/II
 Pause	 Pause / Step / Freeze	 FAV	 Fav / Marker / PC
 Red/Zoom	 Red / Netflix / Search	 Green/9 Pic.	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat	 Blue	 Blue / Prime Video / Random
 << / Tune-	 << / Tune-	 >> / Tune+	 >> / Tune+
 Sub-T	 Subtitle / EQ		



