







































































| Originale | | Sostituto | | Originale | | Sostituto | |
|-------------------------------------------------------------------------------------|-------|-------------------------------------------------------------------------------------|-----------------------|---------------------------------------------------------------------------------------|----------------|---------------------------------------------------------------------------------------|-----------------------------|
|  | Mute |  | Mute / Dimmer |  | Up |  | Up |
|  | Power |  | Power |  | Left |  | Left |
|  | Setup |  | Setup / OPT / |  | Enter |  | OK |
|  | Zoom |  | Zoom / Size |  | Right |  | Right |
|  | Mode |  | Picture / Format |  | Down |  | Down |
|  | Angle |  | Info / Angle |  | Music |  | Sound / Title |
|  | Sub-T |  | Subtitle / EQ |  | Menu |  | Menu / Home |
|  | Video |  | 4 |  | Display |  | Display / Media |
|  | I<< |  | I<< / Preset- |  | Audio |  | Audio / Lang I/II |
|  | >>I |  | >>I / Preset+ |  | OTB |  | Guide / EPG / -/- |
|  | Vol+ |  | Vol+ |  | Repeat |  | Green / APP / Repeat |
|  | << |  | << / Tune- |  | Interval Time |  | Sleep / Timer |
|  | >> |  | >> / Tune+ |  | Slide Show |  | TV/Radio / |
|  | Vol- |  | Vol- |  | DVD Play |  | Blue / Prime Video / Random |
|  | Stop |  | Stop / Hold |  | P/N |  | Red / Netflix / Search |
|  | Play |  | Play / Slow |  | Preview On/Off |  | Fav / Marker / PC |
|  | Pause |  | Pause / Step / Freeze |  | SR |  | Smart / List |



