





























































Originale	Sostituto
 Power	 Power
 Setup	 Setup / OPT /
 Open/Close	 Eject / Surround
 Title	 Sound / Title
 PBC/Menu	 Menu / Home
 Goto	 Shift + Text /
 Display	 Display / Media
 Mute	 Mute / Dimmer
 Subtitle	 Subtitle / EQ
 Audio	 Audio / Lang I/II
 Angle	 Info / Angle
 Play	 Play / Slow
 Up	 Up
 Stop	 Stop / Hold
 Left	 Left
 Enter	 OK
 Right	 Right

Originale	Sostituto
 <<	 << / Tune-
 Down	 Down
 >>	 >> / Tune+
 I<<	 I<< / Preset-
 Slow	 AV / Input / RDS
 Pause	 Pause / Step / Freeze
 >>I	 >>I / Preset+
 Zoom	 Zoom / Size
 Prog	 TV/Radio /
 Bookmark	 Green / APP / Repeat
 Return	 Back / Return
 1	 1
 2	 2
 3	 3
 C	 Yellow / YouTube / Repeat
 4	 4
 5	 5



