

































| Originale   | Sostituto   | Originale | Sostituto   |
|-------------|---|-----------|---|
| PWR On/Off  |  Power             | 1. ?      |  1                           |
| Mute        |  Mute / Dimmer     | 2abc      |  2                           |
| Audio       |  Audio / Lang I/II | 3def      |  3                           |
| Sleep Timer |  Sleep / Timer     | 4ghi      |  4                           |
| TV          |  TV/Radio /        | 5jkl      |  5                           |
| Text        |  Text / Goto       | 6mno      |  6                           |
| Video       |  AV / Input / RDS  | 7pqrm     |  7                           |
| Menu        |  Menu / Home       | 8tuv      |  8                           |
| Menu Up     |  Up                | 9wxyz     |  9                           |
| Menu Left   |  Left             | 0/10      |  0                          |
| Menu Right  |  Right           | FAV Pref. |  Fav / Marker / PC         |
| Menu Down   |  Down            | Red       |  Red / Netflix / Search    |
| Volume+     |  Vol+            | Yellow    |  Yellow / YouTube / Repeat |
| CH/Page+    |  CH+ / Page+     | TV        |  Shift + 1                 |
| Volume-     |  Vol-            | Video     |  Shift + 4                 |
| Display     |  Display / Media |           |   |
| CH/Page-    |  CH- / Page-     |           |   |

