






























Originale	Sostituto
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Lang.	 Audi o / Lang I / II
 0	 0
 [=] . .	 Subtitle / EQ
 Vol +	 Vol +
 Mute	 Mute / Di mmer
 P+	 CH+ / Page+
 Vol -	 Vol -

Originale	Sostituto
 Voi ce	 Di spl ay / Medi a
 P-	 CH / Page-
 Home	 Shi ft + Menu /
 Gui de	 Gui de / EPG / - / -
 i	 I nf o / Angl e
 Up	 Up
 Lef t	 Lef t
 OK	 OK
 Ri ght	 Ri ght
 ←	 Back / Ret ur n
 Down	 Down
 Exi t	 Exi t / Cance l / Cle ar
 Net fl i x	 Shi ft + Red / Net fl i x /
 You Tube	 Shi ft + Yel low / You Tube /
 FPay	 Shi ft + Gre en / APP /
 Googl e Pl ay	 Shi ft + Bl ue / Pri ne
 Menu	 Menu / Home





Originale	Sostituto
 Source	 AV / Input / RDS
 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 <<	 << / Tune-
 Stop	 Stop / Hold
 >>	 >> / Tune+
 Rec	 Rec / Rec Mode
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 Text	 Text / Goto

Originale	Sostituto

