







































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Left		Left
	Pause		Pause		Goto		Guide
	Mute		Mute		Play		Play
	I<</Prev		I<<		Stop		Stop
	>>I/Next		>>I		Repeat		Text
	<</FR		<<		Tv System		TV/R
	>>/FF		>>		Option		Shift + Options
	Home		Smart		Zoom		Eject
	I>/Slow		Media		i/Display		Info
	Return		Back		Audio		Dual
	Setup		Options		AV/YBPBR		AV
	Vol+		Vol +		A-B		Format
	Vol-		Vol -		aA/Subtitle		Subt
	OK		Ok		Red		Red
	Up		Up		Yellow		Yellow
	Down		Down		Blue		Blue
	Right		Right		Green		Green

