




Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Left	 Left
 Mute	 Mute	 OK	 Ok
 1	 1	 Right	 Right
 2	 2	 Down	 Down
 3	 3	 FAV	 Pre Ch
 4	 4	 EPG	 Guide
 5	 5	 V+	 Vol +
 6	 6	 V-	 Vol -
 7	 7	 Info	 Info
 8	 8	 Audio	 Dual
 9	 9	 Text	 Text
 0	 0	 P+	 Ch +
 SAT	 Smart	 P-	 Ch -
 Tv/R	 TV/R	 Red	 Red
 Menu	 Menu	 RCL	 Options
 Exit	 Exit	 Green/Pause	 Green
 Up	 Up	 Yellow	 Yellow




Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Left	 Left
 Mute	 Mute	 OK	 Ok
 1	 1	 Right	 Right
 2	 2	 Down	 Down
 3	 3	 FAV	 Pre Ch
 4	 4	 EPG	 Guide
 5	 5	 V+	 Vol +
 6	 6	 V-	 Vol -
 7	 7	 Info	 Info
 8	 8	 Audio	 Dual
 9	 9	 Text	 Text
 0	 0	 P+	 Ch +
 SAT	 Smart	 P-	 Ch -
 Tv/R	 TV/R	 Red	 Red
 Menu	 Menu	 RCL	 Options
 Exit	 Exit	 Green/Pause	 Green
 Up	 Up	 Yellow	 Yellow







Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Left	 Left
 Mute	 Mute	 OK	 Ok
 1	 1	 Right	 Right
 2	 2	 Down	 Down
 3	 3	 FAV	 Pre Ch
 4	 4	 EPG	 Guide
 5	 5	 V+	 Vol +
 6	 6	 V-	 Vol -
 7	 7	 Info	 Info
 8	 8	 Audio	 Dual
 9	 9	 Text	 Text
 0	 0	 P+	 Ch +
 SAT	 Smart	 P-	 Ch -
 Tv/R	 TV/R	 Red	 Red
 Menu	 Menu	 RCL	 Options
 Exit	 Exit	 Green/Pause	 Green
 Up	 Up	 Yellow	 Yellow









Originale	Sostituto	Originale	Sostituto
 MUTE	 SHIFT	 TV	 DVD
 DVD	 SAT	 AUX	 REC MODE
 PLAY MODE	 II	 ■	 ●
 II	 ■	 ●	 ●
 <<<	 <<	 >>>	 >>
 <<	 <<	 >>>	 >>
 DISC NAV	 SOUND	 AD	 SETTINGS
 LIST	 DUAL	 SUBT	 OPT
 PROG	 SEARCH	 PICTURE	 ECO
 SLEEP	 TV/R	 FORMAT	 3D
 E-MANUAL	 REPEAT	 ZOOM	 TIMER
 D.MENU	 TEXT	 ▲	 AV
 TOP MENU	 DISPLAY	 INFO	 INFO
 MENU	 ▲	 OK	 ▼
 CLEAR	 ←	 →	 →
 EXIT	 OK	 →	 →
 + VOL	 HOME	 SMART	 + CH
 - VOL	 APP	 MEDIA	 - CH
 1	 2	 3	 4
 2	 3	 4	 5
 3	 4	 5	 6
 4	 5	 6	 7
 5	 6	 7	 8
 6	 7	 8	 9
 7	 8	 9	 0
 8	 9	 0	 FAV
 9	 0	 FAV	 PRE-CH
 0	 PRE-CH	 PRE-CH	 PRE-CH
 GUIDE	 A	 B	 C
 0	 B	 C	 D
 A	 B	 C	 D
 B	 C	 D	 D
 A	 B	 C	 D
 B	 C	 D	 D
 A	 B	 C	 D
 B	 C	 D	 D
 A	 B	 C	 D
 B	 C	 D	 D
 A	 B	 C	 D
 B	 C	 D	 D
 A	 B	 C	 D
 B	 C	 D	 D
 A	 B	 C	 D
 B	 C	 D	 D
 A	 B	 C	 D
 B	 C	 D	 D







Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Left	 Left
 Mute	 Mute	 OK	 Ok
 1	 1	 Right	 Right
 2	 2	 Down	 Down
 3	 3	 FAV	 Pre Ch
 4	 4	 EPG	 Guide
 5	 5	 V+	 Vol +
 6	 6	 V-	 Vol -
 7	 7	 Info	 Info
 8	 8	 Audio	 Dual
 9	 9	 Text	 Text
 0	 0	 P+	 Ch +
 SAT	 Smart	 P-	 Ch -
 Tv/R	 TV/R	 Red	 Red
 Menu	 Menu	 RCL	 Options
 Exit	 Exit	 Green/Pause	 Green
 Up	 Up	 Yellow	 Yellow

Originale	Sostituto	Originale	Sostituto
 Left	 Left	 Left	 Left
 OK	 Ok	 Left	 Left
 Right	 Right	 Right	 Right
 Down	 Down	 Down	 Down
 FAV	 Pre Ch	 FAV	 Pre Ch
 EPG	 Guide	 EPG	 Guide
 V+	 Vol +	 V+	 Vol +
 V-	 Vol -	 V-	 Vol -
 Info	 Info	 Info	 Info
 Audio	 Dual	 Audio	 Dual
 Text	 Text	 Text	 Text
 P+	 Ch +	 P+	 Ch +
 P-	 Ch -	 P-	 Ch -
 Red	 Red	 Red	 Red
 RCL	 Options	 RCL	 Options
 Green/Pause	 Green	 Green/Pause	 Green
 Yellow	 Yellow	 Yellow	 Yellow



