















Originale		Sostituto		Originale		Sostituto	
	Power		Power		Blue/[]		Blue
	Vol+		Vol +		Info		Info
	Vol-		Vol -		Text		Text
	PR+		Ch +		1		1
	PR-		Ch -		2		2
	Mute		Mute		3		3
	Menu		Menu		4		4
	Exit		Exit		5		5
	Back		Back		6		6
	OK		Ok		7		7
	Up		Up		8		8
	Down		Down		9		9
	Right/Zoom+		Right		0/-/--		0
	Left/Zoom-		Left		AV		AV
	Red/[o]		Red		SP/LP		Media
	Green/Timer/List		Green		Play		Play
	Yellow		Yellow		>>		>>





Originale		Sostituto		Originale		Sostituto	
	<<		<<				
	Stop		Stop				
	Pause		Pause				
	Rec		Rec				
	Mark		3D				
	0000		Guide				











Originale		Sostituto		Originale		Sostituto	
	Power		Power		Blue/[]		Blue
	Vol+		Vol +		Info		Info
	Vol-		Vol -		Text		Text
	Mute		Mute		Play		Play
	PR+		Ch +		Stop		Stop
	PR-		Ch -		Rec		Rec
	Exit		Exit		Pause		Pause
	Menu		Menu		>>		>>
	Back		Back		<<		<<
	Up		Up		1		1
	Down		Down		2		2
	Right/Zoom+		Right		3		3
	Left/Zoom-		Left		4		4
	OK		Ok		5		5
	Red/[o]		Red		6		6
	Green/Timer/List		Green		7		7
	Yellow		Yellow		8		8





Originale		Sostituto		Originale		Sostituto	
	9		9				
	AV		AV				
	SP/LP		Media				





Originale	Sostituto
Power	Power
Vol+	Vol +
Vol-	Vol -
Mute	Mute
PR+	Ch +
PR-	Ch -
Menu	Menu
Exit	Exit
Back	Back
Up	Up
Down	Down
Right/Zoom+	Right
Left/Zoom-	Left
OK	Ok
Red/[o]	Red
Green/Timer/List	Green
Yellow	Yellow

Originale	Sostituto
Blue/[]	Blue
Info	Info
Text	Text
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0/-/--	0
AV	AV
SP/LP	Media
Play	Play
Stop	Stop





Originale	Sostituto	Originale	Sostituto
FWD >>	>>		
REV <<	<<		
REC Rec	REC MODE Rec		
PAUSE Pause	Pause		
MARK Mark	ECO 3D 3D		
0000 0000	GUIDE Guide		

Originale	Sostituto

