




















| Originale   | Sostituto   |
|---|---|
|    |  Power                   |
|    |  Info / Angle            |
|    |  Audio / Lang I/II       |
|    |  Mute / Dimmer           |
|    |  Subtitle / EQ           |
|    |  Fav / Marker / PC       |
|    |  Shift + Up              |
|    |  Text / Goto             |
|    |  Guide / EPG / -/--      |
|    |  Shift + Down            |
|   |  Menu / Home            |
|  |  CH+ / Page+           |
|  |  Up                    |
|  |  Exit / Cancel / Clear |
|  |  Left                  |
|  |  Vol-                  |
|  |  OK                    |

| Originale   | Sostituto  |
|---|--|
|    |  Right            |
|    |  Vol+             |
|    |  Smart / List     |
|    |  CH- / Page-      |
|    |  Down             |
|    |  Back / Return    |
|    |  1                |
|    |  2                |
|    |  3                |
|    |  Picture / Format |
|   |  4               |
|  |  5              |
|  |  6              |
|  |  TV/Radio /     |
|  |  7              |
|  |  8              |
|  |  9              |





| Originale | Sostituto                   | Originale | Sostituto |
|-----------|-----------------------------|-----------|-----------|
| 0         | 0                           |           |           |
| I<<       | I<< / Preset-               |           |           |
| <<        | << / Tune-                  |           |           |
| >>        | >> / Tune+                  |           |           |
| >>        | >>  / Preset+               |           |           |
| Play      | Play / Slow                 |           |           |
| Pause     | Pause / Step / Freeze       |           |           |
| Stop      | Stop / Hold                 |           |           |
| Rec       | Rec / Rec Mode              |           |           |
| Red/Timer | Sleep / Timer               |           |           |
| Red/Timer | Red / Netflix / Search      |           |           |
| Eject     | Eject / Surround            |           |           |
| Green     | Green / APP / Repeat        |           |           |
| Yellow    | Yellow / YouTube / Repeat   |           |           |
| Blue      | Blue / Prime Video / Random |           |           |

| Originale | Sostituto |
|-----------|-----------|
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |
|           |           |

