




















































































































































































































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 Menu	 Menu
 Mute	 Mute	 EPG	 Guide
 1	 1	 Exit	 Exit
 2	 2	 OK	 Ok
 3	 3	 Up	 Up
 4	 4	 Down	 Down
 5	 5	 Right	 Right
 6	 6	 Left	 Left
 7	 7	 CH+	 Ch +
 8	 8	 CH-	 Ch -
 9	 9	 Vol+	 Vol +
 0	 0	 Vol-	 Vol -
 FAV	 Pre Ch	 Red	 Red
 Recall	 Back	 Green	 Green
 Game	 Media	 Yellow	 Yellow
 Auto	 Smart	 Blue	 Blue
 Info	 Info	 Zoom	 Eject

Originale	Sostituto	Originale	Sostituto
 MUTE	 MUTE	 SHIFT	 SHIFT
 TV	 TV	 DVD	 DVD
 SAT	 SAT	 AUX	 AUX
 PLAY MODE	 PLAY MODE	 REC MODE	 REC MODE
 FF	 FF	 STOP	 STOP
 PAUSE	 PAUSE	 PLAY	 PLAY
 RR	 RR	 SETTINGS	 SETTINGS
 SOUND	 SOUND	 OPT	 OPT
 AD	 AD	 ECO	 ECO
 PICTURE	 PICTURE	 3D	 3D
 SLEEP	 SLEEP	 AV	 AV
 TV/R	 TV/R	 DUAL	 DUAL
 FORMAT	 FORMAT	 SUBT	 SUBT
 ZOOM	 ZOOM	 REPEAT	 REPEAT
 TIMER	 TIMER	 TEXT	 TEXT
 E-MANUAL	 E-MANUAL	 UP	 UP
 D.MENU	 D.MENU	 DOWN	 DOWN
 TOP MENU	 TOP MENU	 INFO	 INFO
 MENU	 MENU	 OK	 OK
 CLEAR	 CLEAR	 RETURN	 RETURN
 EXIT	 EXIT	 BACK	 BACK
 HOME	 HOME	 CH +	 CH +
 SMART	 SMART	 CH -	 CH -
 APP	 APP	 VOL +	 VOL +
 MEDIA	 MEDIA	 VOL -	 VOL -
 VOL +	 VOL +	 1	 1
 VOL -	 VOL -	 2	 2
 1	 1	 3	 3
 2	 2	 4	 4
 3	 3	 5	 5
 4	 4	 6	 6
 5	 5	 7	 7
 6	 6	 8	 8
 7	 7	 9	 9
 8	 8	 0	 0
 9	 9	 FAV	 FAV
 0	 0	 GUIDE	 GUIDE
 FAV	 FAV	 PRE-CH	 PRE-CH
 GUIDE	 GUIDE	 A	 A
 PRE-CH	 PRE-CH	 B	 B
 A	 A	 C	 C
 B	 B	 D	 D
 C	 C	 ZOOM	 ZOOM
 D	 D	 Eject	 Eject



