

















































Originale		Sostituto		Originale		Sostituto	
	Power		Power		0		0
	Mute		Mute		Menu		Menu
	FAV		Pre Ch		Exit		Exit
	Subtitle		Subt		Up		Up
	Info		Info		Left		Left
	TTX		Text		OK		Ok
	Recall		Back		Right		Right
	List		List		Down		Down
	1		1		EPG		Guide
	2		2		Vol +		Vol +
	3		3		Vol -		Vol -
	4		4		Timer		AV
	5		5		Pg Dn		Shift + Ch -
	6		6		Pg Up		Shift + Ch +
	7		7		<<		<<
	8		8		>>		>>
	9		9		I<<		I<<



















































	Originale	Sostituto	Originale	Sostituto
		>>I		>>I
		CH +		Ch +
		CH -		Ch -
		Play		Play
		Pause		Pause
		Stop		Stop
		Audio		Dual
		PAL / NTSC		3D
		Sleep		Sleep
		TV / Radio		TV/R
		Red		Red
		Aspect		Format
		Green		Green
		Yellow		Yellow
		Blue		Blue







Originale		Sostituto		Originale		Sostituto	
	Power		Power		0		0
	Mute		Mute		Menu		Menu
	FAV		Pre Ch		Exit		Exit
	Subtitle		Subt		Up		Up
	Info		Info		Left		Left
	TTX		Text		OK		Ok
	Recall		Back		Right		Right
	List		List		Down		Down
	1		1		EPG		Guide
	2		2		Vol +		Vol +
	3		3		Vol -		Vol -
	4		4		Timer		AV
	5		5		Pg Dn		Shift + Ch -
	6		6		Pg Up		Shift + Ch +
	7		7		<<		<<
	8		8		>>		>>
	9		9		I<<		I<<






















Originale		Sostituto	
	>>I		>>I
	CH +		Ch +
	CH -		Ch -
	Play		Play
	Pause		Pause
	Stop		Stop
	Audio		Dual
	PAL / NTSC		3D
	Sleep		Sleep
	TV / Radio		TV/R
	Red		Red
	Aspect		Format
	Green		Green
	Yellow		Yellow
	Blue		Blue


















Originale		Sostituto	







Originale	Sostituto	Originale	Sostituto
Power		Power	Power
Mute		Mute	Mute
FAV		Pre Ch	Pre Ch
Subtitle		Subt	Subt
Info		Info	Info
TTX		Text	Text
List		List	List
Recall		Back	Back
1		1	1
2		2	2
3		3	3
4		4	4
5		5	5
6		6	6
7		7	7
8		8	8
9		9	9

Originale	Sostituto	Originale	Sostituto
0		0	0
Menu		Menu	Menu
Exit		Exit	Exit
EPG		Guide	Guide
Swap		Media	Media
Up		Up	Up
Down		Down	Down
Right		Right	Right
Left		Left	Left
OK		Ok	Ok
Vol+		Vol +	Vol +
Vol-		Vol -	Vol -
Pg Up		Shift + Up	Shift + Up
PG Dn		Shift + Down	Shift + Down
CH+		Ch +	Ch +
CH-		Ch -	Ch -
>>		>>	>>





Originale	Sostituto	Originale	Sostituto
<<		<<	
>>		>>	
I<<		I<<	
Play		Play	
Pause/Timeshift		Pause	
Stop		Stop	
Rec		Rec	
Audio		Dual	
M/P		Smart	
Tv/Radio		TV/R	
A-B		Options	
Red/Zoom		Red	
Green/Aspect		Green	
Yellow/V-Formet		Yellow	
Blue/Timer		Blue	

