



Originale	Sostituto
	Mute / Dimmer
	Power
	1
	2
	3
	4
	5
	6
	7
	8
	9
	0
	AV / Input / RDS
	Menu / Home
	CH+ / Page+
	Up

Originale	Sostituto
	Text / Got o
	Vol -
	Left
	OK
	Vol +
	Right
	Back / Ret urn
	CH- / Page-
	Down
	Pi ct ure / For mat
	Inf o / Angl e
	Red / Netfl ix / Search
	Green / APP / Repeat
	Yel low / You Tube / Repeat
	Bl ue / Pri ne Vi deo / Random
	St op / Hol d
	Di spl ay / Medi a



