







































































| Originale   |               | Sostituto  |                             | Originale   |             | Sostituto   |                            |
|---|---------------|--|-----------------------------|---|-------------|---|----------------------------|
|    | Power         |     | Power                       |    | 4           |    | 4                          |
|    | Red / ↑       |     | Red / Netflix / Search      |    | 5           |    | 5                          |
|    | green / ↓     |     | Green / APP / Repeat        |    | 6           |    | 6                          |
|    | Yellow        |     | Yellow / YouTube / Repeat   |    | 7           |    | 7                          |
|    | Blue          |     | Blue / Prime Video / Random |    | 8           |    | 8                          |
|    | Exit          |     | Exit / Cancel / Clear       |    | 9           |    | 9                          |
|    | [≡o]          |     | Sleep / Timer               |    | P<P/Swap    |    | Picture / Format           |
|    | [≡+]          |     | Stop / Hold                 |    | 0           |    | 0                          |
|    | [≡x]          |     | Smart / List                |    | -/--        |    | Shift + Guide / EPG / -/-- |
|    | [≡]           |     | Text / Goto                 |    | Vol-        |    | Vol-                       |
|   | [ /≡]         |    | Setup / OPT /               |   | Vol+        |   | Vol+                       |
|  | [≡♦]/[+]/Wide |   | Menu / Home                 |  | Mute        |  | Mute / Dimmer              |
|  | [≡?]          |  | Shift + Info / Angle        |  | P-          |  | CH- / Page-                |
|  | [≡i]/Guide    |   | Guide / EPG / -/--          |  | P+          |  | CH+ / Page+                |
|  | 1             |   | 1                           |  | [i]/Info    |  | Info / Angle               |
|  | 2             |   | 2                           |  | Tv/DTV      |  | TV/Radio /                 |
|  | 3             |   | 3                           |  | [AV]/Source |  | AV / Input / RDS           |



