













































































































Originale	Sostituto
 Power	 Power
 Rec	 Rec / Rec Mode
 [ ]X	 Exit / Cancel / Clear
 EQ	 Shift + Subtitle / EQ
 Mute	 Mute / Dimmer
 →[ ]←	 Picture / Format
 1	 1
 2	 2
 3	 3
 [Z]	 Subtitle / EQ
 4	 4
 5	 5
 6	 6
 [Z]<	 Audio / Lang I/II
 7	 7
 8	 8
 9	 9

Originale	Sostituto
 (Z)))	 Zoom / Size
 0	 0
 +10	 Fav / Marker / PC
 Time	 Sleep / Timer
 Prog	 Shift + TV/Radio / Program
 Setup/Mem	 Setup / OPT /
 Title	 Sound / Title
 Up	 Up
 Left/FAV-	 Left
 Enter	 OK
 Right/FAV+	 Right
 Menu/PBC	 Menu / Home
 Down	 Down
 Return/Exit	 Back / Return
 Function	 D.Menu / Top
 DVD Source	 AV / Input / RDS
 Tv/Radio	 TV/Radio /





Originale	Sostituto	Originale	Sostituto
	Stop		Stop / Hold
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Slow		Shift + Play /
	Display		Display / Media
	<</Tuning-		<< / Tune-
	>>/Tuning+		>> / Tune+
	l<<		l<< / Preset-
	CH-		CH- / Page-
	CH+		CH+ / Page+
	>>l		>>l / Preset+
	Teletext		Text / Goto
	EPG		Guide / EPG / -/--
	Vol-		Vol-
	Vol+		Vol+
	Red/Repeat		Red / Netflix / Search
	Green/A-B		Green / APP / Repeat

Originale	Sostituto	Originale	Sostituto
	Yellow/Zoom		Yellow / YouTube / Repeat
	Blue/Clear		Blue / Prime Video / Random

