






































































Originale		Sostituto		Originale		Sostituto	
	Power		Power		Vol+		Vol +
	Mute		Mute		Vol-		Vol -
	1		1		CH+		Ch +
	2		2		CH-		Ch -
	3		3		Up		Up
	4		4		Down		Down
	5		5		Right		Right
	6		6		Left		Left
	7		7		OK		Ok
	8		8		Exit		Exit
	9		9		Menu		Menu
	0		0		Red/DVD Setup		Red
	CH.List		List		Green/Repeat		Green
	Recall		Pre Ch		Yellow/Languag		Yellow
	PIC.Mode		Shift + Format		Blue/DVD Menu		Blue
	S.Mode		Shift + Dual		Title/Aspect		3D
	Source		AV		Zoom/Tv/Radio		TV/R



