










































Originale	Sostituto	Originale	Sostituto
 Power	 Power	 P+	 Up
 1	 1	 V-	 Vol-
 2	 2	 V-	 Left
 3	 3	 Menu	 Menu / Home
 4	 4	 Menu	 OK
 5	 5	 V+	 Vol+
 6	 6	 V+	 Right
 7	 7	 P-	 CH- / Page-
 8	 8	 P-	 Down
 9	 9	 Tv	 TV/Radio /
 Mute	 Mute / Dimmer	 Exit	 Exit / Cancel / Clear
 0	 0	 Av	 AV / Input / RDS
 16:9	 Picture / Format	 Red	 Red / Netflix / Search
 S/M/D	 Display / Media	 Green	 Green / APP / Repeat
 PP	 Back / Return	 Yellow	 Yellow / YouTube / Repeat
 →←	 Smart / List	 Blue	 Blue / Prime Video / Random
 P+	 CH+ / Page+	 ≡Text	 Text / Goto

Originale	Sostituto	Originale	Sostituto
 P+	 Up	 TV	 DVD
 V-	 Left	 Exit	 SAT
 Menu	 Menu / Home	 Av	 AUX
 Menu	 OK	 Red	 REC MODE
 V+	 Vol+	 Green	 SLOW STEP-FREEZE
 V+	 Right	 Yellow	 HOLD
 P-	 CH- / Page-	 Blue	 PRESET-
 P-	 Down	 ≡Text	 PRESET+
 Tv	 TV/Radio /	 ≡Text	 EQ SURROUND
 Exit	 Exit / Cancel / Clear	 ≡Text	 TITLE LANG UI EQ
Av	AV / Input / RDS	≡Text	SOUND AUDIO SUBTITLE
Red	Red / Netflix / Search	≡Text	FORMAT SIZE TIMER PROGRAM
Green	Green / APP / Repeat	≡Text	PICTURE ZOOM SLEEP
Yellow	Yellow / YouTube / Repeat	≡Text	TOP MENU OPT-TOOLS GOTO
Blue	Blue / Prime Video / Random	≡Text	D.MENU SETUP TEXT
≡Text	Text / Goto	≡Text	HOME HOME





Originale	Sostituto
 /≡Mix	 Audio / Lang I/II
 ≡☺Time Page	 Subtitle / EQ
 Info	 Info / Angle
 ≡i	 Guide / EPG / -/--
 ≡x	 Fav / Marker / PC
 ≡◇	 Setup / OPT /
 ≡x	 Zoom / Size
 ≡? Reveal	 D.Menu / Top

Originale	Sostituto

