



Originale	Sostituto
 Power	 Power
 Mute	 Mute / Dimmer
 Red	 Red / Netflix / Search
 Green / Aspect	 Green / APP / Repeat
 Green / Aspect	 Picture / Format
 Yellow	 Yellow / YouTube / Repeat
 Blue / SUBT	 Subtitle / EQ
 Blue / SUBT	 Blue / Prime Video / Random
 <<	 << / Tune-
 >>	 >> / Tune+
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 USB	 Shift + 8
 Play / Pause	 Play / Slow
 Play / Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 Rec	 Rec / Rec Mode

Originale	Sostituto
 F1 / Find	 D.Menu / Top
 F2 / Zoom	 Zoom / Size
 F2 / Zoom	 Setup / OPT /
 F3 / TXT	 Smart / List
 F3 / TXT	 Text / Goto
 F4	 Display / Media
 Menu	 Menu / Home
 Up / CH+	 Up
 Info	 Info / Angle
 Left / Vol-	 Left
 OK	 OK
 Right / Vol+	 Right
 FAV	 Fav / Marker / PC
 Down / CH-	 Down
 Exit	 Exit / Cancel / Clear
 Vol+	 Vol+
 EPG	 Guide / EPG / -/-











































Originale	Sostituto
 Power	 Power
 Mute	 Mute / Dimmer
 Red	 Red / Netflix / Search
 Green / Aspect	 Picture / Format
 Green / Aspect	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue / SUBT	 Subtitle / EQ
 Blue / SUBT	 Blue / Prime Video / Random
 <<	 << / Tune-
 >>	 >> / Tune+
 I<<	 I<< / Preset-
 >>I	 >>I / Preset+
 USB	 Shift + 8
 Play / Pause	 Play / Slow
 Play / Pause	 Pause / Step / Freeze
 Stop	 Stop / Hold
 Rec	 Rec / Rec Mode

Originale	Sostituto
 F1 / Find	 D.Menu / Top
 F2 / Zoom	 Setup / OPT /
 F2 / Zoom	 Zoom / Size
 F3 / TXT	 Text / Goto
 F3 / TXT	 Smart / List
 F4	 Display / Media
 Menu	 Menu / Home
 Up / CH+	 Up
 Info	 Info / Angle
 Left / Vol-	 Left
 OK	 OK
 Right / Vol+	 Right
 FAV	 Fav / Marker / PC
 Down / CH-	 Down
 Exit	 Exit / Cancel / Clear
 Vol+	 Vol+
 EPG	 Guide / EPG / -/-



