



| Originale | Sostituto |
|---|---|
|  Power |  Power |
|  Home |  Shift + Menu / |
|  1 / Add / Red |  1 |
|  1 / Add / Red |  Red / Netflix / Search |
|  2 / Eject / Green |  Green / APP / Repeat |
|  2 / Eject / Green |  Eject / Surround |
|  2 / Eject / Green |  2 |
|  3 / Delete / Yellow |  3 |
|  3 / Delete / Yellow |  Yellow / YouTube / Repeat |
|  4 / Zoom |  4 |
|  4 / Zoom |  Zoom / Size |
|  5 / Goto / Blue |  Blue / Prime Video / Random |
|  5 / Goto / Blue |  5 |
|  5 / Goto / Blue |  Text / Goto |
|  6 / Menu |  Menu / Home |
|  6 / Menu |  6 |
|  7 / Setup |  7 |

| Originale | Sostituto |
|--|---|
|  7 / Setup |  Setup / OPT / |
|  8 / Func |  8 |
|  9 / TV Out |  TV/Radio / |
|  9 / TV Out |  9 |
|  Info |  Info / Angle |
|  0 / Preview |  0 |
|  Return |  Back / Return |
|  Up |  Up |
|  Left |  Left |
|  Enter |  OK |
|  Right |  Right |
|  Down |  Down |
|  I<< / PGUP |  I<< / Preset- |
|  Play / Pause |  Play / Slow |
|  Play / Pause |  Pause / Step / Freeze |
|  Stop |  Stop / Hold |
|  >>I / PGDN |  >>I / Preset+ |



