



Originale	Sostituto
Power	Power
Info	Help / Info
Menu/Exit	Menu
Auto	Auto
Eco Blank	Shift + Mute / Blank / Mute
Source	Source
Up/Keystone +	Up
Down/Keystone-	Down
Right	Right
Left	Left
Mode Enter	Enter
Smart Eco	Eco / Aspect
Aspect	Shift + Eco / Aspect
Vol+	Vol + / Page +
Vol-	Vol - / Page -
Mute	Blank / Mute
Digital Zoom+	+ / Play

Originale	Sostituto
Digital Zoom-	- / Stop
Page Up	Shift + Vol + / Page +
Page Down	Shift + Vol - / Page -
Freeze	Freeze / Timer
On Timer	Shift + Freeze / Timer
CC	Shift + Source
Quick Install	Comp / Video
Setup Timer	Mode
3D Settings	3D / Invert
Teaching	Volt / Focus

